

VICTREX FG™ POLYMER 200/201

General Information

Product Description

High performance Food Grade thermoplastic material, unreinforced PolyEtherEtherKetone (PEEK), semi crystalline, granules for injection moulding and extrusion, colour natural/beige (200) and black (201).

The VICTREX FG™ 200 family of materials is intended for applications needing toughness and ductility from sub-ambient to elevated temperatures along with long-term fatigue resistance and low coefficient of thermal expansion for metal replacement. Chemically resistant to aggressive environments, suitable for sterilisation.

Material Properties

| Physical | Nominal Value | Unit | Test Method |
|---|---------------|-------------------|-----------------|
| Density (Crystalline) | 1.30 | g/cm ³ | ISO 1183 |
| Spiral Flow ¹ | 12.5 | cm | Internal Method |
| Molding Shrinkage ² | | | ISO 294-4 |
| Across Flow | 1.3 | % | |
| Flow | 1.0 | % | |
| Water Absorption (Saturation, 23°C) | 0.45 | % | ISO 62 |
| Water Absorption - Saturation (100°C) | 0.55 | % | ISO 62 |
| Mechanical | Nominal Value | Unit | Test Method |
| Tensile Stress (Yield, 23°C) | 95.0 | MPa | ISO 527-2 |
| Tensile Strain (Break, 23°C) | 60 | % | ISO 527-2 |
| Flexural Modulus (23°C) | 3600 | MPa | ISO 178 |
| Flexural Stress | | | ISO 178 |
| 23°C | 155 | MPa | |
| 125°C | 85.0 | MPa | |
| 175°C | 16.0 | MPa | |
| Compressive Stress | | | ISO 604 |
| 23°C | 120 | MPa | |
| 120°C | 65.0 | MPa | |
| Tensile Fatigue - 1e6 cycles, 2 Hz (23°C) | 80.0 | MPa | |
| Impact | Nominal Value | Unit | Test Method |
| Notched Izod Impact Strength (23°C) | 9.5 | kJ/m ² | ISO 180/A |
| Unnotched Izod Impact Strength (23°C) | No Break | | ISO 180 |
| Hardness | Nominal Value | Unit | Test Method |
| Shore Hardness (Shore D, 23°C) | 84.0 | | ISO 868 |

VICTREX FG™ POLYMER 200/201

| Thermal | Nominal Value | Unit | Test Method |
|--|---------------|---------|-------------|
| Deflection Temperature Under Load 1.8 MPa, Unannealed | 152 | °C | ISO 75-2/Af |
| Glass Transition Temperature | | | ISO 11357-2 |
| Onset | 143 | °C | |
| Midpoint | 150 | °C | |
| Melting Temperature | 343 | °C | ISO 11357-3 |
| CLTE - Flow | | | ISO 11359-2 |
| < 143°C | 45 | ppm/K | |
| > 143°C | 125 | ppm/K | |
| CLTE - Average | | | ISO 11359-2 |
| < 143°C | 65 | ppm/K | |
| > 143°C | 160 | ppm/K | |
| Thermal Conductivity ³ (23°C) | 0.29 | W/m/K | ISO 22007-4 |
| Electrical | Nominal Value | Unit | Test Method |
| Volume Resistivity (23°C) | 1.0E+16 | ohms-cm | IEC 60093 |
| Dielectric Strength (2.00 mm) | 23.0 | kV/mm | IEC 60243-1 |

Typical Processing Information

| Injection | Nominal Value | Unit |
|------------------------|---------------|------|
| Drying Temperature | 120 to 150 | °C |
| Drying Time | 3.0 to 5.0 | hr |
| Suggested Max Moisture | 0.020 | % |
| Hopper Temperature | < 100 | °C |
| Rear Temperature | 375 | °C |
| Middle Temperature | 380 to 385 | °C |
| Front Temperature | 390 | °C |
| Nozzle Temperature | 395 | °C |
| Mold Temperature | 170 to 200 | °C |

Injection Notes

Runner: Die / nozzle >3mm, manifold >3.5mm

Gate: >1mm or 0.5 x part thickness

Important notes:

1) Processing conditions quoted in our datasheets are typical of those used in our processing laboratories

- Data for mould shrinkage should be used for material comparison. Actual mould shrinkage values are highly dependent on part geometry, mould configuration, and processing conditions.
- Mould shrinkage differs for along flow and across flow directions. "Along flow" direction is taken as the direction the molten material is travelling when it exits the gate and enters the mould.
- Mould shrinkage is expressed as a percent change in dimension of a specimen in relation to mould dimensions.

2) Data are generated in accordance with prevailing national, international and internal standards, and should be used for material comparison. Actual property values are highly dependent on part geometry, mould configuration and processing conditions. Properties may also differ for along flow and across flow directions.

Detailed data available on our website www.victrex.com or upon request.

Notes

¹ Mold Temperature: 180°C, Melt Temperature: 395°C, 1.00 mm

² 395°C nozzle, 180°C tool

³ Average

VICTREX FG™ POLYMER 200/201

Revision Date: December 2023

This information is provided "as is". It is not intended to amount to advice. Use of the product is at the customer's/user's risk. It is the customer's/user's responsibility to thoroughly test the product in each specific application to determine its performance, efficacy and safety for each end-use product, device or other application and compliance with applicable laws, regulations and standards. Mention of a product is no guarantee of availability. Victrex reserves the right to modify products, data sheets, specifications and packaging. **Victrex makes no warranties, express or implied (including, without limitation, any warranty of fitness for a particular purpose or of intellectual property non-infringement) and will not be liable for any loss or damage of any nature (however arising) in connection with customer's/user's use or reliance on this information, except for any liability which cannot be excluded or limited by law.** This document may be modified or retracted at any time without notice to the customer/user.

Victrex Manufacturing Limited (or another member of the Victrex group) is the owner or the licensee of all intellectual property rights in and to this document including the following trademarks, VICTREX, INVIBIO, JUVORA, APTIV, 450G, PEEK-OPTIMA, SHAPING FUTURE PERFORMANCE, LMPAEK, TRIANGLE (Device). All rights are protected by intellectual property rights including copyright under relevant national and international intellectual property laws and treaties. All rights reserved. Copyright © Victrex Manufacturing Limited 2023.