

# VICTREX HPG™ POLYMER 140 GRA

## General Information

### Product Description

High performance thermoplastic material, unreinforced PolyEtherEtherKetone (PEEK), semi crystalline, granules for injection moulding, standard flow, colour natural. Chemically resistant to aggressive environments

## Material Properties

| Physical                       | Nominal Value | Unit              | Test Method     |
|--------------------------------|---------------|-------------------|-----------------|
| Density (Crystalline)          | 1.30          | g/cm <sup>3</sup> | ISO 1183        |
| Spiral Flow <sup>1</sup>       | 12.0          | cm                | Internal Method |
| Molding Shrinkage <sup>2</sup> |               |                   | ISO 294-4       |
| Across Flow                    | 1.3           | %                 |                 |
| Flow                           | 0.90          | %                 |                 |
| Mechanical                     | Nominal Value | Unit              | Test Method     |
| Tensile Modulus                |               |                   | ISO 527-1       |
| 23°C                           | 3700          | MPa               |                 |
| 80°C                           | 3500          | MPa               |                 |
| 120°C                          | 3300          | MPa               |                 |
| 160°C                          | 600           | MPa               |                 |
| Tensile Stress                 |               |                   | ISO 527-2       |
| Yield, 23°C                    | 95.0          | MPa               |                 |
| Yield, 80°C                    | 70.0          | MPa               |                 |
| Yield, 120°C                   | 50.0          | MPa               |                 |
| Tensile Strain (Break, 23°C)   | 32            | %                 | ISO 527-2       |
| Flexural Modulus               |               |                   | ISO 178         |
| 23°C                           | 3700          | MPa               |                 |
| 80°C                           | 3300          | MPa               |                 |
| 120°C                          | 3200          | MPa               |                 |
| 160°C                          | 500           | MPa               |                 |
| Flexural Stress                |               |                   | ISO 178         |
| 3.5% Strain, 23°C              | 120           | MPa               |                 |
| 23°C <sup>3</sup>              | 150           | MPa               |                 |
| 80°C <sup>3</sup>              | 110           | MPa               |                 |
| 120°C <sup>3</sup>             | 85.0          | MPa               |                 |
| 160°C <sup>3</sup>             | 25.0          | MPa               |                 |
| Compressive Modulus            |               |                   | ISO 604         |
| 23°C                           | 3700          | MPa               |                 |
| 80°C                           | 3400          | MPa               |                 |
| 120°C                          | 3300          | MPa               |                 |
| 160°C                          | 600           | MPa               |                 |
| Compressive Stress             |               |                   | ISO 604         |
| 23°C                           | 120           | MPa               |                 |
| 80°C                           | 100           | MPa               |                 |
| 120°C                          | 80.0          | MPa               |                 |

# VICTREX HPG™ POLYMER 140 GRA

| Impact                                | Nominal Value | Unit              | Test Method |
|---------------------------------------|---------------|-------------------|-------------|
| Charpy Notched Impact Strength (23°C) | 7.0           | kJ/m <sup>2</sup> | ISO 179/A   |
| Notched Izod Impact Strength          | 7.2           | kJ/m <sup>2</sup> | ISO 180     |
| Thermal                               | Nominal Value | Unit              | Test Method |
| Glass Transition Temperature (Onset)  | 143           | °C                | ISO 11357-2 |
| Melting Temperature                   | 343           | °C                | ISO 11357-3 |
| Fill Analysis                         | Nominal Value | Unit              | Test Method |
| Melt Viscosity (400°C)                | 450           | Pa·s              | ISO 11443   |

## Typical Processing Information

| Injection              | Nominal Value | Unit |
|------------------------|---------------|------|
| Drying Temperature     | 120 to 150    | °C   |
| Drying Time            | 3.0 to 5.0    | hr   |
| Suggested Max Moisture | 0.020         | %    |
| Hopper Temperature     | < 100         | °C   |
| Rear Temperature       | 375           | °C   |
| Middle Temperature     | 380 to 385    | °C   |
| Front Temperature      | 390           | °C   |
| Nozzle Temperature     | 395           | °C   |
| Mould Temperature      | 170 to 200    | °C   |

### Injection Notes

Drying Temperature / Time: 150°C / 3h or 120°C / 5h (residual moisture <0.02%)

Runner: Die / nozzle >3mm, manifold >3.5mm

Gate: >1mm or 0.5 x part thickness

Important notes:

1) Processing conditions quoted in our datasheets are typical of those used in our processing laboratories

- Data for mould shrinkage should be used for material comparison. Actual mould shrinkage values are highly dependent on part geometry, mould configuration, and processing conditions.
- Mould shrinkage differs for along flow and across flow directions. "Along flow" direction is taken as the direction the molten material is travelling when it exits the gate and enters the mould.
- Mould shrinkage is expressed as a percent change in dimension of a specimen in relation to mould dimensions.

2) Data are generated in accordance with prevailing national, international and internal standards, and should be used for material comparison.

Actual property values are highly dependent on part geometry, mould configuration and processing conditions. Properties may also differ for along flow and across flow directions.

Detailed data available on our website [www.victrex.com](http://www.victrex.com) or upon request.

## Notes

<sup>1</sup> Mould Temperature: 180°C, Melt Temperature: 395°C, 1.00 mm

<sup>2</sup> 395°C nozzle, 180°C tool

<sup>3</sup> At yield

**Revision Date: March 2026**

This information is provided "as is". It is not intended to amount to advice. Use of the product is at the customer's/user's risk. It is the customer's/user's responsibility to thoroughly test the product in each specific application to determine its performance, efficacy and safety for each end-use product, device or other application and compliance with applicable laws, regulations and standards. Mention of a product is no guarantee of availability. Victrex reserves the right to modify products, data sheets, specifications and packaging. **Victrex makes no warranties, express or implied (including, without limitation, any warranty of fitness for a particular purpose or of intellectual property non-infringement) and will not be liable for any loss or damage of any nature (however arising) in connection with customer's/user's use or reliance on this information, except for any liability which cannot be excluded or limited by law.** This document may be modified or retracted at any time without notice to the customer/user.

Victrex Manufacturing Limited (or another member of the Victrex group) is the owner or the licensee of all intellectual property rights in and to this document including the following trademarks, VICTREX, 450G, VICTREX AM, VICTREX CT, VICTREX FG, VICTREX HPG, VICTREX HT, VICTREX ST, VICTREX WG, APTIV, LMPAEK, VICOTE, TRIANGLE (Device). All rights are protected by intellectual property rights including copyright under relevant national and international intellectual property laws and treaties. All rights reserved. Copyright © Victrex Manufacturing Limited 2026.