

VICTREX™ PEEK POLYMER 151G

General Information

Product Description

High performance thermoplastic material, unreinforced PolyEtherEtherKetone (PEEK), semi crystalline, depth filtered granules for injection moulding, easy flow, colour natural/beige.

Typical Application Areas

Complex geometries with thin cross sections or long flow lengths, for high strength and stiffness as well as good ductility. Chemically resistant to aggressive environments. Suitable for steam sterilisation. Further information is available on request.

Material Properties

Physical	Nominal Value	Unit	Test Method
Density (Crystalline)	1.30	g/cm ³	ISO 1183
Spiral Flow			Internal Method
-- 1	22.0	cm	
-- 2	25.0	cm	
-- 3	30.0	cm	
Molding Shrinkage ⁴			ISO 294-4
Across Flow	1.3	%	
Flow	1.0	%	
Water Absorption (Saturation, 23°C)	0.45	%	ISO 62
Water Absorption Saturation (100°C)	0.55	%	ISO 62
Mechanical	Nominal Value	Unit	Test Method
Tensile Modulus (23°C)	4100	MPa	ISO 527-1
Tensile Stress (Yield, 23°C)	105	MPa	ISO 527-2
Tensile Strain (Break, 23°C)	30	%	ISO 527-2
Flexural Modulus (23°C)	3900	MPa	ISO 178
Flexural Stress			ISO 178
3.5% Strain, 23°C	130	MPa	
23°C ⁵	175	MPa	
125°C	90.0	MPa	
175°C	20.0	MPa	
275°C	13.5	MPa	
Compressive Stress			ISO 604
23°C	130	MPa	
120°C	80.0	MPa	
Impact	Nominal Value	Unit	Test Method
Charpy Notched Impact Strength (23°C)	4.2	kJ/m ²	ISO 179/1eA
Charpy Unnotched Impact Strength (23°C)	No Break		ISO 179/1U
Notched Izod Impact Strength (23°C)	4.2	kJ/m ²	ISO 180/A
Unnotched Izod Impact Strength (23°C)	No Break		ISO 180/1U
Hardness	Nominal Value	Unit	Test Method
Shore Hardness (Shore D, 23°C)	85.0		ISO 868

VICTREX™ PEEK POLYMER 151G

Thermal	Nominal Value	Unit	Test Method
Deflection Temperature Under Load			ISO 75-2/Af
1.8 MPa, Unannealed	156	°C	
1.8 MPa, Annealed ⁶	167	°C	
Glass Transition Temperature			ISO 11357-2
Onset	143	°C	
Midpoint	147	°C	
Melting Temperature	343	°C	ISO 11357-3
CLTE - Flow			ISO 11359-2
< 143°C	50	ppm/K	
> 143°C	120	ppm/K	
CLTE - Average			ISO 11359-2
< 143°C	55	ppm/K	
> 143°C	140	ppm/K	
Thermal Conductivity			ISO 22007-4
23°C ⁷	0.29	W/m/K	
23°C ⁸	0.32	W/m/K	
RTI Elec	260	°C	UL 746B
RTI Imp	180	°C	UL 746B
RTI Str	240	°C	UL 746B
Electrical	Nominal Value	Unit	Test Method
Volume Resistivity			IEC 60093
23°C	1.0E+16	ohms·cm	
125°C	1.0E+15	ohms·cm	
275°C	1.0E+9	ohms·cm	
Dielectric Strength (2.00 mm)	23.0	kV/mm	IEC 60243-1
Dielectric Constant (23°C, 1 kHz)	3.10		IEC 60250
Dissipation Factor (23°C, 1 MHz)	4.0E-3		IEC 60250
Comparative Tracking Index	150	V	IEC 60112
Flammability	Nominal Value	Unit	Test Method
Glow Wire Flammability Index (2.0 mm)	960	°C	IEC 60695-2-12
Fill Analysis	Nominal Value	Unit	Test Method
Melt Viscosity (400°C)	130	Pa·s	ISO 11443

Typical Processing Information

Injection	Nominal Value	Unit
Drying Temperature	120 to 150	°C
Drying Time	3.0 to 5.0	hr
Suggested Max Moisture	0.020	%
Hopper Temperature	< 100	°C
Rear Temperature	350	°C
Middle Temperature	355	°C
Front Temperature	360	°C
Nozzle Temperature	365	°C
Mould Temperature	160 to 200	°C

Injection Notes

Runner: Die / nozzle >3mm, manifold >3.5mm
Gate: >1mm or 0.5 x part thickness

Important notes:

1) Processing conditions quoted in our datasheets are typical of those used in our processing laboratories

- Data for mould shrinkage should be used for material comparison. Actual mould shrinkage values are highly dependent on part geometry, mould configuration, and processing conditions.
- Mould shrinkage differs for along flow and across flow directions. "Along flow" direction is taken as the direction the molten material is travelling when it exits the gate and enters the mould.
- Mould shrinkage is expressed as a percent change in dimension of a specimen in relation to mould dimensions.

2) Data are generated in accordance with prevailing national, international and internal standards, and should be used for material comparison. Actual property values are highly dependent on part geometry, mould configuration and processing conditions. Properties may also differ for along flow and across flow directions.

Detailed data available on our website www.victrex.com or upon request.

Notes

¹ Mould Temperature: 160°C, Melt Temperature: 365°C, 1.00 mm
² Mould Temperature: 180°C, Melt Temperature: 375°C, 1.00 mm
³ Mould Temperature: 200°C, Melt Temperature: 400°C, 1.00 mm
⁴ 365°C nozzle, 160°C tool
⁵ At yield
⁶ 200°C/4h
⁷ Average
⁸ Along flow

Revision Date: December 2024

This information is provided "as is". It is not intended to amount to advice. Use of the product is at the customer's/user's risk. It is the customer's/user's responsibility to thoroughly test the product in each specific application to determine its performance, efficacy and safety for each end-use product, device or other application and compliance with applicable laws, regulations and standards. Mention of a product is no guarantee of availability. Victrex reserves the right to modify products, data sheets, specifications and packaging. **Victrex makes no warranties, express or implied (including, without limitation, any warranty of fitness for a particular purpose or of intellectual property non-infringement) and will not be liable for any loss or damage of any nature (however arising) in connection with customer's/user's use or reliance on this information, except for any liability which cannot be excluded or limited by law.** This document may be modified or retracted at any time without notice to the customer/user.

Victrex Manufacturing Limited (or another member of the Victrex group) is the owner or the licensee of all intellectual property rights in and to this document including the following trademarks, VICTREX, 450G, VICTREX AM, VICTREX CT, VICTREX FG, VICTREX HPG, VICTREX HT, VICTREX ST, VICTREX WG, APTIV, LMPAEK, VICOTE, TRIANGLE (Device). All rights are protected by intellectual property rights including copyright under relevant national and international intellectual property laws and treaties. All rights reserved. Copyright © Victrex Manufacturing Limited 2025.