



# VICOTE™ COATINGS F804BLK

---

## General Information

---

### Product Description

VICOTE F804Blk (Black) Aqueous Dispersion For Use on Ferrous and Non-Ferrous Metals VICOTE is the brand name for the Victrex range of coatings. VICOTE Coatings are available through Victrex or its preferred coater network.

VICOTE F804Blk has been specifically formulated to provide a resilient coating with high wear and abrasion resistance on ferrous and non-ferrous substrates such as carbon steel, cast steel and aluminium. These properties are retained at high temperatures where other coatings would potentially fail. Typical properties are high continuous use temperature of 260°C, excellent wear, abrasion and cut through resistance at these high temperatures, combined with excellent chemical and radiation resistance. VICOTE dispersions have a low level of extractables and inherently flame retardant. Contact Victrex for further details.

#### VICOTE F804Blk Dispersion

VICOTE F804Blk dispersions are aqueous based; however, there are small amounts of solvents present. Refer to the appropriate MSDS sheet for details.

The VICTREX™ PEEK polymer contained in the VICOTE dispersion like other non-coating grades of VICTREX PEEK polymer are thermoplastic in nature and exhibit flow above the melt temperature. When processed using the correct guidelines the coatings will exhibit the excellent properties that VICTREX PEEK polymer is renowned for. For further chemical resistance information consult the Victrex Chemical Resistance Data brochure.

### SUBSTRATES AND PREPARATION

VICOTE can be applied to most ferrous and non-ferrous substrates. A primer is not required. Cast metals need to be de-gassed in an oven to prevent pin holes in the coating surface. Substrates should be free from grease, oils and corrosion prior to coating. Solvent de-greasing and grit blasting with aluminium oxide with final solvent wash should ensure a suitable surface for coating. Note: Phosphate pre-treated substrates are not recommended for VICOTE grades as the high processing temperatures required for processing can result in de-lamination of the coating.

### SPRAYING

A conventional gravity fed spray gun with a nozzle size between 0.7 and 1.0mm has been found suitable for applying VICOTE dispersions. Edges of components should be sprayed first before applying a complete coating. An air pressure to the gun of between 35 and 50 psi has been found to be a suitable spray pressure. Spray at right angles to the substrate wherever possible. The spray gun and cup can be cleaned with water after use.

### PROCESSING

For general processing information consult the VICOTE dispersion coating guides. Coated parts should be dried in air for 5 minutes then dried in an oven for 5 minutes at 120°C before placing in an oven at 400°C to melt and fuse the coating.

By following the processing guide smooth coatings should be achievable. Because VICOTE materials are semi crystalline thermoplastics, as with all these types of products shrinkage will take place when the coating cools. Depending on the mass of the substrate, coating thickness and the rate of cooling will determine the amount of shrinkage.

Normally processed and cooled coatings should result in crystalline coatings which should not require further post processing treatment. However, an increase in crystallinity may enhance certain properties such as wear and scratch resistance. To anneal the coating the part should be placed in an air circulating oven and the temperature raised at 10°C per minute to 250°C and held at that temperature for 30 minutes to 1 hour.

With coated parts that are subject to a high service temperature it may be beneficial to anneal the parts at 10°C above the maximum service temperature to prevent further volume change of the coating.

### STORAGE AND HANDLING CONSIDERATIONS

VICOTE drums should be stored in a clean dry environment and should not be stored with the lids removed as this may result in airborne dust contaminating the product, which could cause coating defects.

The VICOTE dispersions will soft settle after prolonged standing. They can be re-dispersed readily by stirring of the liquid suspension. The drums can also be rolled to agitate the dispersion to ensure homogeneity. High shear dispersing should be avoided as the wetting agent is prone to shear thinning. Although it is recommended that the dispersion is not allowed to freeze, re-dispersing after thawing is possible. Optimum storage temperature is 5°C – 25°C.

VICOTE™ COATINGS F804BLK

VICOTE F804Blk is packed in 20 kg polythene UN drums enclosed in a strong cardboard box with the VICOTE logo.

SAFETY PRECAUTIONS  
Before applying VICOTE dispersions, read the appropriate Material Safety Data Sheet (MSDS) and the processing guide, available from Victrex.

VICOTE F804Blk coatings should be only applied using suitable exhaust ventilation. Care should be taken not to inhale fumes or vapours. The washing of hands and good housekeeping are a prerequisite before handling these products.

Material Properties			
Mechanical	Nominal Value	Unit	Test Method
Coefficient of Friction @ 10 min. <sup>1</sup>	0.608	µm	ASTM G133
Thermal	Nominal Value	Unit	Test Method
Glass Transition Temperature <sup>2</sup>			ISO 11357-2
Onset	143	°C	
Midpoint	147	°C	
Melting Temperature <sup>2</sup>	343	°C	ISO 11357-3
Additional Information	Nominal Value	Unit	Test Method
Conical Bend <sup>3</sup>	Pass at 3.2	sec	
Cross Hatch Adhesion Aluminum <sup>4</sup>	0		ISO 2409
Cross Hatch Adhesion Mild Steel <sup>4</sup>	0		ISO 2409
Cross Hatch Adhesion Stainless Steel <sup>4</sup>	0		ISO 2409
Direct Impact Height	1	m	ISO 6272-1
Direct Impact Indentation depth	15	mm	ISO 6272-1
Direct Impact Weight	1	kg	ISO 6272-1
König Hardness <sup>5</sup> (40.0 to 50.0 µm)	205	sec	ISO 1522
Typical Property Data for VICOTE F804BLK Coating on Film Thickness 25 - 30 µm			

- Notes
- <sup>1</sup> Using 100N Load
- <sup>2</sup> Thermal analysis data of the PAEK polymer used in the VICOTE coating formulation
- <sup>3</sup> BS EN ISO 6860
- <sup>4</sup> Rating 0 to 5
- <sup>5</sup> Minimum coating thickness required for this test was 30 µm

Revision Date: October 2024

This information is provided "as is". It is not intended to amount to advice. Use of the product is at the customer's/user's risk. It is the customer's/user's responsibility to thoroughly test the product in each specific application to determine its performance, efficacy and safety for each end-use product, device or other application and compliance with applicable laws, regulations and standards. Mention of a product is no guarantee of availability. Victrex reserves the right to modify products, data sheets, specifications and packaging. **Victrex makes no warranties, express or implied (including, without limitation, any warranty of fitness for a particular purpose or of intellectual property non-infringement) and will not be liable for any loss or damage of any nature (however arising) in connection with customer's/user's use or reliance on this information, except for any liability which cannot be excluded or limited by law.** This document may be modified or retracted at any time without notice to the customer/user.

Victrex Manufacturing Limited (or another member of the Victrex group) is the owner or the licensee of all intellectual property rights in and to this document including the following trademarks, VICTREX, 450G, VICTREX AM, VICTREX CT, VICTREX FG, VICTREX HPG, VICTREX HT, VICTREX ST, VICTREX WG, APTIV, LMPAEK, VICOTE, TRIANGLE (Device). All rights are protected by intellectual property rights including copyright under relevant national and international intellectual property laws and treaties. All rights reserved. Copyright © Victrex Manufacturing Limited 2025.