



VICTREX® PEEK COATING TECHNOLOGY

## 700 SERIES ELECTROSTATIC POWDER COATINGS PRODUCT DATA SHEET

### VICOTE® 701, 702, 703, 704, 705, 706 and 707 Powder Coatings

VICOTE® is the brand name for VICTREX® PEEK polymer-based coatings. VICOTE Coatings are only available through Victrex or its preferred coater network. Contact Victrex for further details.

#### PROPERTIES

VICOTE 701-707 grades are specially developed powder coatings. They are available in various average particle sizes from 10 - 50 microns. The powders are off-white in color and are available in various melt viscosities depending on the film thickness and level of melt flow required. Typical film thicknesses range from < 100 microns up to 500 microns. Film thicknesses above 1 mm are possible by building up the coating thickness by the hot flocking technique.

Like other non-coating grades of VICTREX PEEK polymer, VICOTE Coatings are thermoplastic in nature and exhibit flow above the melt temperature. When processed using the correct guidelines, the coatings will exhibit the excellent properties that VICTREX PEEK polymer is renowned for.

- High continuous use temperature of 260°C
- Excellent wear, abrasion and cut through resistance at these high temperatures
- Excellent chemical and radiation resistance
- Low level of extractables
- Hydrolysis resistant
- Inherently flame retardant

#### Typical Properties of 701-707 Grade Powder Coatings

Property	Test Method	Units	Value
Density	ISO 1183	g cm <sup>3</sup>	1.32
Melt Temp.	DSC	°C	343
Glass Transition	DSC	°C	143
CUT (RTI)	UL746B	°C	260
Konig Hardness	BS EN ISO 1522	seconds	200

#### FDA COMPLIANCE

Materials and articles manufactured from VICOTE grades 701, 702, 703, 704, 705, 706, 707 comply with

the compositional requirements of regulation 21 CFR 175.300 for resinous and polymeric coatings of the Food and Drug Administration (FDA) of the United States of America.

Regulation 21 CFR 175.300 further specifies that the finished coated part which is in contact with food is subject to extractive limitations. Compliance with any applicable extractive limits can only be demonstrated by testing carried out on the finished article.

#### SUBSTRATES AND PREPARATION

VICOTE coatings can be applied to most ferrous and non-ferrous metals. A primer is not required.

- Cast metals need to be de-gassed in an oven to prevent pin holes in the coating surface. Aluminium may be coated. However, the mechanical properties of the Aluminium will be affected at VICOTE coatings processing temperatures.
- Substrates should be free from grease, oils and corrosion prior to coating. Solvent de-greasing and grit blasting with Aluminium Oxide with final solvent wash should ensure a suitable surface for coating.

**Note:** phosphate pre-treated substrates are not recommended for VICOTE coating grades as the high processing temperatures required for processing can result in de-lamination of the coating.

#### PROCESSING

Conventional electrostatic spray equipment is suitable for VICOTE coating products. Ovens should be capable of attaining up to 450°C. For general processing information consult the VICOTE powder coating guide.

- By following the processing guide, smooth coatings should be achievable. VICOTE materials are semi-crystalline thermoplastics, and as with all these types of products, shrinkage will take place when the coating cools. Depending on the mass of the substrate, coating thickness and rate of cooling will determine the amount of shrinkage.

- Normally processed and cooled coatings should result in crystalline coatings, which should not require further post processing treatment. However, an increase in crystallinity may enhance certain properties such as wear and scratch resistance. To anneal the coating, the part should be placed in an air circulating oven and the temperature raised at 10°C per minute to 250°C and held at that temperature for 30 minutes to 1 hour.
- With coated parts that are subject to a high service temperature, it may be beneficial to anneal the parts at 10°C above the maximum service temperature to prevent further volume change of the coating.

**Note:** The colour of the final coating when using VICOTE 700 series natural resins may depend on the substrate. For example, if a thin VICOTE Coating is applied, the processing temperatures will turn some steels blue and may impart a blue/grey colour to the final VICOTE Coating.

#### STORAGE AND HANDLING CONSIDERATIONS

- VICOTE boxes should be stored in a clean dry environment and should not be stored with the lids and internal liner opened as this may result in airborne dust contaminating the product, which could cause coating defects.
- VICOTE Powder Coatings are packed in 10kg strong cardboard boxes with the VICOTE logo on the outside. Smaller quantities are available on request.

- The powders have an indefinite storage life if the powder is kept sealed in its original box.
- Drying the powders at 150°C for 3 hours or 120°C overnight is recommended before use.

#### SAFETY PRECAUTIONS

- Before applying VICOTE Powder Coatings, read the appropriate Material Safety Data Sheet (MSDS) and the processing guide, available from Victrex.
- VICOTE natural coating resins should only be applied using suitable local exhaust ventilation system.
- Care should be taken not to inhale dust, vapors and fumes evolved during processing.
- VICOTE Coatings must only be applied and processed where Local Extract Ventilation (LEV) is available.
- Washing of hands and good housekeeping are a prerequisite before handling these products.

**Note:** these products are not for human implantation.

#### World Headquarters

Victrex plc  
Hillhouse International  
Thornton Cleveleys  
Lancashire FY5 4QD  
United Kingdom  
Tel: + (44) 1253 897700  
Fax: + (44) 1253 897701  
Email: victrexplc@victrex.com

#### Americas

Victrex USA Inc  
300 Conshohocken State Road  
Suite 120  
West Conshohocken, PA 19428  
USA  
Tel: + (1) 800-VICTREX  
Tel: + (1) 484-342-6001  
Fax: + (1) 484-342-6002  
Email: americas@victrex.com

#### Europe

Victrex Europa GmbH  
Langgasse 16  
65719 Hofheim/Ts.  
Germany  
Tel: + (49) 6192 96490  
Fax: + (49) 6192 964948  
Email: eurossales@victrex.com

#### Asia Pacific

Victrex Japan Inc.  
Mita Kokusai Building Annex  
4-28, Mita 1-chome  
Minato-ku  
Tokyo 108-0073  
Japan  
Tel: +81 (0)3 5427 4650  
Tel: +81 (0)3 5427 4651  
Email: japansales@victrex.com

#### Asia Pacific

Victrex High Performance  
Materials (Shanghai) Co Ltd  
Part B Building G  
No. 1688 Zhuanxing Road  
Xinzhuang Industry Park  
Shanghai 201108  
China  
Tel: + (86) 21-6113 6900  
Fax: + (86) 21-6113 6901  
Email: scsales@victrex.com

VICTREX PLC BELIEVES THAT THE INFORMATION CONTAINED IN THIS BROCHURE IS AN ACCURATE DESCRIPTION OF THE TYPICAL CHARACTERISTICS AND/OR USES OF THE PRODUCT OR PRODUCTS, BUT IT IS THE CUSTOMER'S RESPONSIBILITY TO THOROUGHLY TEST THE PRODUCT IN EACH SPECIFIC APPLICATION TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY FOR EACH END-USE PRODUCT, DEVICE OR OTHER APPLICATION. SUGGESTIONS OF USES SHOULD NOT BE TAKEN AS INDUCEMENTS TO INFRINGE ANY PARTICULAR PATENT. THE INFORMATION AND DATA CONTAINED HEREIN ARE BASED ON INFORMATION WE BELIEVE RELIABLE. MENTION OF A PRODUCT IN THIS DOCUMENTATION IS NOT A GUARANTEE OF AVAILABILITY. VICTREX PLC RESERVES THE RIGHT TO MODIFY PRODUCTS, SPECIFICATIONS AND/OR PACKAGING AS PART OF A CONTINUOUS PROGRAM OF PRODUCT DEVELOPMENT. VICTREX® IS A REGISTERED TRADEMARK OF VICTREX MANUFACTURING LIMITED. VICTREX PIPES™ IS A TRADEMARK OF VICTREX MANUFACTURING LIMITED. PEEK-ESD™, HT™, ST™ AND WGT™ ARE TRADEMARKS OF VICTREX PLC. VICOTE® AND APTIV® ARE REGISTERED TRADEMARKS OF VICTREX PLC.

VICTREX PLC MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, A WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR OF INTELLECTUAL PROPERTY NON-INFRINGEMENT, INCLUDING, BUT NOT LIMITED TO PATENT NON-INFRINGEMENT, WHICH ARE EXPRESSLY DISCLAIMED, WHETHER EXPRESS OR IMPLIED, IN FACT OR BY LAW. FURTHER, VICTREX PLC MAKES NO WARRANTY TO YOUR CUSTOMERS OR AGENTS, AND HAS NOT AUTHORIZED ANYONE TO MAKE ANY REPRESENTATION OR WARRANTY OTHER THAN AS PROVIDED ABOVE. VICTREX PLC SHALL IN NO EVENT BE LIABLE FOR ANY GENERAL, INDIRECT, SPECIAL, CONSEQUENTIAL, PUNITIVE, INCIDENTAL OR SIMILAR DAMAGES, INCLUDING WITHOUT LIMITATION, DAMAGES FOR HARM TO BUSINESS, LOST PROFITS OR LOST SAVINGS, EVEN IF VICTREX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, REGARDLESS OF THE FORM OF ACTION.