



VICOTE®

VICTREX® PEEK COATING TECHNOLOGY

700 SERIES POWDER COATINGS PRODUCT DATA SHEET

VICOTE® 705Blk (Black) Powder Coatings

VICOTE is the brand name for the Victrex range of powder coating resins. The VICOTE range of VICTREX® PEEK polymer is only available through Victrex or its preferred coater network. Contact Victrex for further details.

PROPERTIES

VICOTE 705Blk is a black pigmented version of the 705 grade. This grade has a nominal particle size of ~ 50 microns. The powder is dark grey in colour and is a low melt viscosity grade for lower film builds. Typical film thicknesses range from 50 – 80 microns. The final coating takes on a dark gun metal grey colour after stoving.

VICOTE Coatings, like other noncoating grades of VICTREX PEEK polymer, are thermoplastic in nature and exhibit flow above the melt temperature. When processed using the correct guidelines the coatings will exhibit the excellent properties that VICTREX PEEK polymer is renowned for.

Typical properties are high continuous use temperature of 260°C, excellent wear, abrasion and cut through resistance at these high temperatures combined with excellent chemical and radiation resistance. VICOTE Coatings have a low level of extractables and are hydrolysis resistant and inherently flame retardant.

SUBSTRATES AND PREPARATION

VICOTE Coatings can be applied to most ferrous and non ferrous metals. A primer is not required. Cast metals need to be de-gassed in an oven to prevent pin holes in the coating surface. Aluminium may be coated however the mechanical properties of the metal will be affected at the VICOTE Coating processing temperatures.

Substrates should be free from grease, oils and corrosion prior to coating. Solvent de-greasing and

grit blasting with aluminium oxide with final solvent wash should ensure a suitable surface for coating.

Note: phosphate pre-treated substrates are not recommended for VICOTE Coating grades as the high processing temperatures required for processing can result in de-lamination of the coating.

PROCESSING

Conventional electrostatic spray equipment is suitable for VICOTE Coatings. Ovens should be capable of attaining up to 450°C. For general processing information consult the VICOTE powder coating guides.

By following the processing guide smooth coatings should be achievable. Because VICOTE Coatings are semi crystalline thermoplastics as with all these types of products shrinkage will take place when the coating cools. Depending on the mass of the substrate, coating thickness and rate of cooling will determine the amount of shrinkage.

Normally processed and cooled coatings should result in crystalline coatings which should not require further post processing treatment. However an increase in crystallinity may enhance certain properties such as wear and scratch resistance. To anneal the coating the part should be placed in an air circulating oven and the temperature raised at 10°C per minute to 250°C and held at that temperature for 30 minutes to 1 hour.

With coated parts that are subject to a high service temperature it may be beneficial to anneal the parts at 10°C above the maximum service temperature to prevent further volume change of the coating.

Note: The colour of the final coating when using VICOTE 705Blk may depend on the substrate. For example, if a very thin coating is applied the processing temperatures will affect the colour of the steel which in turn could influence the final colour of the coating.

STORAGE AND HANDLING CONSIDERATIONS

VICOTE boxes should be stored in a clean dry environment and should not be stored with the lids and internal liner opened as this may result in airborne dust contaminating the product, which could cause coating defects.

VICOTE Coatings are packed in 10kg strong cardboard boxes with the VICOTE logo on the outside. Smaller quantities are available on request. The powders have an indefinite storage life if the powder is kept sealed in its original box.

Drying of the powders at 150°C for 3 hours or 120°C overnight is recommended before use.

SAFETY PRECAUTIONS

Before applying VICOTE Coatings, read the appropriate Material Safety Data Sheet (MSDS) and the processing guide, available from Victrex plc.

VICOTE Coatings should be only applied using suitable local exhaust ventilation system.

Care should be taken not to inhale dust, vapour and fumes evolved during processing. VICOTE Coatings must only be applied and processed where Local Extract Ventilation (LEV) is available. Washing of hands and good housekeeping are a pre requisite before handling these products.

Note: these products are not for human implantation.

FDA Compliance

Materials and articles manufactured from VICOTE 705Blk comply with the compositional requirements of regulation 21 CFR 175.300 for resinous and polymeric coatings of the Food and Drug Administration (FDA) of the United States of America.

Regulation 21 CFR 175.300 further specifies that the finished coated part which is in contact with food is subject to extractive limitations. Compliance with any applicable extractive limits can only be demonstrated by testing carried out on the finished article

Typical Property Data for VICOTE® F705Blk Grade Powder Coating

Property	Test Method	Units	Nominal Value
Density	ISO 1183	gcm ³	1.32
Melt Temperature	DSC	°C	343
Glass Transition	DSC	°C	143
CUT (RT1)	UL746B	°C	260
Konig Hardness*	BS EN ISO 1522	seconds	~200

World Headquarters

Victrex plc
Hillhouse International
Thornton Cleveleys
Lancashire FY5 4QD
United Kingdom
Tel: + (44) 1253 897700
Fax: + (44) 1253 897701
Email: victrexplc@victrex.com

Americas

Victrex USA Inc
300 Conshohocken State Road
Suite 120
West Conshohocken, PA 19428
USA
Tel: + (1) 800-VICTREX
Tel: + (1) 484-342-6001
Fax: + (1) 484-342-6002
Email: americas@victrex.com

Europe

Victrex Europa GmbH
Langgasse 16
65719 Hofheim/Ts.
Germany
Tel: + (49) 6192 96490
Fax: + (49) 6192 964948
Email: eurosales@victrex.com

Asia Pacific

Victrex Japan Inc.
Mita Kokusai Building Annex
4-28, Mita 1-chome
Minato-ku
Tokyo 108-0073
Japan
Tel: +81 (0)3 5427 4650
Fax: +81 (0)3 5427 4651
Email: japansales@victrex.com

Asia Pacific

Victrex High Performance
Materials (Shanghai) Co Ltd
Part B Building G
No. 1688 Zhuanxing Road
Xinzhuang Industry Park
Shanghai 201108
China
Tel: + (86) 21-6113 6900
Fax: + (86) 21-6113 6901
Email: scsales@victrex.com

VICTREX PLC BELIEVES THAT THE INFORMATION CONTAINED IN THIS BROCHURE IS AN ACCURATE DESCRIPTION OF THE TYPICAL CHARACTERISTICS AND/OR USES OF THE PRODUCT OR PRODUCTS, BUT IT IS THE CUSTOMER'S RESPONSIBILITY TO THOROUGHLY TEST THE PRODUCT IN EACH SPECIFIC APPLICATION TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY FOR EACH END-USE PRODUCT, DEVICE OR OTHER APPLICATION. SUGGESTIONS OF USES SHOULD NOT BE TAKEN AS INDUCEMENTS TO INFRINGE ANY PARTICULAR PATENT. THE INFORMATION AND DATA CONTAINED HEREIN ARE BASED ON INFORMATION WE BELIEVE RELIABLE. MENTION OF A PRODUCT IN THIS DOCUMENTATION IS NOT A GUARANTEE OF AVAILABILITY. VICTREX PLC RESERVES THE RIGHT TO MODIFY PRODUCTS, SPECIFICATIONS AND/OR PACKAGING AS PART OF A CONTINUOUS PROGRAM OF PRODUCT DEVELOPMENT. VICTREX® IS A REGISTERED TRADEMARK OF VICTREX MANUFACTURING LIMITED. VICTREX PIPESTM IS A TRADEMARK OF VICTREX MANUFACTURING LIMITED. PEEK-ESD™, HT™, ST™ AND WG™ ARE TRADEMARKS OF VICTREX PLC. VICOTE® AND APTIV® ARE REGISTERED TRADEMARKS OF VICTREX PLC.

VICTREX PLC MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, A WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR OF INTELLECTUAL PROPERTY NON-INFRINGEMENT, INCLUDING, BUT NOT LIMITED TO PATENT NON-INFRINGEMENT, WHICH ARE EXPRESSLY DISCLAIMED, WHETHER EXPRESS OR IMPLIED, IN FACT OR BY LAW. FURTHER, VICTREX PLC MAKES NO WARRANTY TO YOUR CUSTOMERS OR AGENTS, AND HAS NOT AUTHORIZED ANYONE TO MAKE ANY REPRESENTATION OR WARRANTY OTHER THAN AS PROVIDED ABOVE. VICTREX PLC SHALL IN NO EVENT BE LIABLE FOR ANY GENERAL, INDIRECT, SPECIAL, CONSEQUENTIAL, PUNITIVE, INCIDENTAL OR SIMILAR DAMAGES, INCLUDING WITHOUT LIMITATION, DAMAGES FOR HARM TO BUSINESS, LOST PROFITS OR LOST SAVINGS, EVEN IF VICTREX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, REGARDLESS OF THE FORM OF ACTION.